




EN



Jiffi
J-40

Folding Kick Scooter

Get there on a Jiffi!

MANUAL

www.scooride.com




Folding Kick Scooter



Get there on a Jiffi!

MANUAL

- ① GRIPS
- ② GRIP SPRING PIN COVER
- ③ GRIP DOCK
- ④ HANDLEBAR
- ⑤ WHEELS
- ⑥ FENDERS
- ⑦ REAR FENDER BRAKE
- ⑧ KICKSTAND
- ⑨ DECK
- ⑩ FOLDING MECHANISM LEVER
- ⑪ QUICK RELEASE LEVER 1
- ⑫ QUICK RELEASE THUMB NUT 1
- ⑬ QUICK RELEASE LEVER 2
- ⑭ QUICK RELEASE THUMB NUT 2



No assembly required. Just unfold it and go!

- Sturdy aircraft-grade aluminum build supports up to 275 lbs.
- Extra-large wheels and shock-absorbing grips for a smooth ride
- Lightweight and kickstand-equipped for easy portability and parking
- Adjustable-height handlebar and super-smooth steering
- Comes with adjustable carrying strap




Folding Kick Scooter



SAFETY ADVISORIES




- ⚠ The Jiffi J-40 scooter is designed for ages 12 and up. Do not allow small children to ride it.
- ⚠ Do not store your Jiffi J-40 scooter where young children have access to it.
- ⚠ Wear shoes when riding your Jiffi J-40 scooter.
- ⚠ Obey traffic signals and signs.
- ⚠ Do not ride in traffic with cars and other motor vehicles.
- ⚠ Avoid wet surfaces and soft ground.
- ⚠ Avoid steep downhill slopes.
- ⚠ The rear fender brake can become hot with use. Do not touch it with bare skin just after braking.
- ⚠ The Jiffi J-40 scooter is built to hold just one person (up to 275 lbs.) at a time.
- ⚠ The Jiffi J-40 scooter is not made for doing tricks and acrobatics.
- ⚠ If riding on rough terrain, consider wearing a helmet, elbow pads, knee pads, and gloves.

- ⚠ Before riding your Jiffi J-40 for the first time, make sure that all screws on the scooter are securely tightened. See the screw diagram included in the box for screw locations.
- ⚠ Ride your Jiffi J-40 scooter only with the front wheel in the proper forward-facing position.



UNFOLDING THE SCOOTER AND GRIPS

Your **Jiffi J-40** comes ready to unfold and ride. There's no assembly required.



To unfold the scooter for the first time—or any time—just follow these steps:

1. Flip quick release lever 1 out.
2. Press the folding mechanism lever down.
3. Pull the handlebar away from the deck until it clicks into place.
4. Fold quick release lever 1 back down

tip

You can adjust the quick release lever tension by turning the quick release thumb nut.

To unfold the handlebar grips, follow these steps:

1. Pull the grip spring pin cover up.
2. Flip quick release lever 2 out so that it's perpendicular to the handlebar column.
3. Pull each grip down slightly and slip it out of the grip dock.
4. Insert each grip into its grip socket.
5. Push each grip in until the grip spring pin snaps into the hole.
6. Fold quick release lever 2 back down against the handlebar column.
7. Fold the grip spring pin cover down.

tip


If the grip spring pin isn't aligned with the hole when you first insert it, twist the grip until the pin appears in the hole.

tip

You can adjust the quick release lever tension by turning the quick release thumb nut.

FOLDING THE SCOOTER AND GRIPS

It's quick and easy to fold the scooter and grips for compact storage or carrying.



To fold the scooter, just follow these steps:


1. Flip quick release lever 1 out.
2. Push the handlebar forward slightly.
3. Press the folding mechanism lock down.
4. Pull the handlebar toward the deck until it clicks into place.
5. Fold quick release lever 1 back down.

To fold the handlebar grips, follow these steps:

1. Pull the grip spring pin cover up.
2. Flip quick release lever 2 out so that it's perpendicular to the handlebar column.
3. With your thumbs, press the grip spring pins in.
4. Pull the grips straight out of their sockets.
5. Fold each grip down below the grip dock and insert the grips into the dock arms from underneath.
6. Fold quick release lever 2 back down against the handlebar column.
7. Fold the grip spring pin cover down.

ADJUSTING THE HANDLEBAR HEIGHT

You can adjust the handlebar to three different height settings.



To move the handlebar up or down, just follow these steps:

1. Flip quick release lever 2 out so that it's perpendicular to the handlebar column.
2. With your thumb, press the handlebar spring pin on the column in.
3. Pull handlebar up or push it down until the handlebar spring pin snaps into the next hole.
4. Fold quick release lever 2 back down against the handlebar column.

tip

You can adjust the quick release lever tension by turning the quick release thumb nut.

RIDING AND BRAKING


Riding the Jiffi J-40 doesn't require much explanation. You just step on with one foot and kick off with the other.

Riding the **Jiffi J-40** doesn't require much explanation. You just step on with one foot and kick off with the other.

To brake with the rear fender, use your kicking foot to press the fender lightly so that you feel the friction.

Apply more pressure as necessary to slow down or come to a stop.


Here are a few tips for a smooth ride:



- Let the foot you're kicking with rest behind your standing foot on the deck between kicks.
- Practice riding down a slight incline to get a sense of how to control the scooter before you get into a busy area.
- Avoid steep inclines. The scooter will pick up speed quickly going downhill, and you could lose control.
- Don't be afraid to just jump off. That's the quickest way to stop when you need to, and the Jiffi J-40 deck is built low to the ground to make jumping off easy.
- You can flip the kickstand down with your foot when you want to park or leave the Jiffi standing for a few minutes.

Leave the carrying strap clipped on when you ride your Jiffi J-40. It's designed not to interfere with your ride.


MAINTAINING YOUR JIFFI



- Store your Jiffi J-40 in a clean, dry place.
- The self-tightening screws on the scooter can loosen over time, especially with a lot of riding on bumpy terrain. Check them periodically to make sure they're tight, and tighten them with a compatible hex key or Phillips head screwdriver if needed.
- Should any part or hardware piece become damaged, please contact Scooride for information about replacements and repairs.

SPECIFICATIONS

- **Handlebar height:** adjustable from 31.5" (80 cm) to 40.9" (104 cm)
- **Length:** 37.4" (95 cm)
- **Deck:** 18.1" x 5.4" (46 x 13.7 cm)
- **Wheel diameter:** 7.9" (200 mm)
- **Folded size:** 33" x 13" x 5.3" (84 x 33 x 13.5 cm)
- **Weight:** 8.8 lbs. (4 kg)
- **Weight capacity:** 275 lbs. (125 kg)





Scooride ® 2 Mill St. Cornwall NY 12518

Web: www.scooride.com

US: 1-800-574-9323, Support@scooride.com

UK: 020-3150-0484, Support@scooride.com.uk